


LCLS Injector Quadrupole Magnet FIDUCIALIZATION REPORT



Inspector:	Keith Caban
Responsible Engineer:	Roger Carr
Date:	Thursday, June 01, 2006
Work Order/Charge No.:	92-4215-8
Serial Number	000392

Part Set-up – Coordinate System Set-up

Planar Alignment

- Mid-Plane of the magnet

Spatial Alignment


- A line on the top part of the magnet
 - +X goes towards (Magnet Info Label)

“Z” Zero

- Mid-Plane of the magnet


“X” & “Y” Zero

- On both ends
 - Tangent point of each radii (4 on each end, 8 total).
 - Create a line between diagonal tangent points creates 2 lines.
 - Intersect the lines.
 - Creates a point on each end.
- Create a line of these 2 end points
 - This is the “X” & “Y” Zero, and Beamline or “Z” Axis.



Tooling Ball Measurements/Locations

Top of magnet; view from "+Y"



Tooling Ball	FORM	DIAMETER	X	Y	Z
TB 1	0.00059	0.49678	6.49881	9.37655	-1.24800
TB 2	0.00138	0.49657	-6.49983	9.37797	-1.24908
TB 3	0.00026	0.49886	-6.49995	9.37722	1.24974
TB 4	0.00071	0.49662	6.49852	9.37716	1.24964

Additional Requested Measurements

View From +Z


Tangent Point Straightness

- A. 0.00021
- B. 0.00017
- C. 0.00011
- D. 0.00018

Parallelism to Beamline

- A. 0.00019
- B. 0.00022
- C. 0.00036
- D. 0.00023

Distance of opposite Tangent Axis



A-C = 1.25992 (0.62985, 0.63006)

B-D = 1.25899 (0.62956, 0.62943)